

7 Leonard Street, Hornsby NSW 2077 Australia-P.O. Box 1664, Hornsby Westfield NSW 1635
Tel: (02) 9476 4544 • Fax: (02) 9477 7974 • Int'l +61-2 • E-mail: kelba@kelba.com • Web Site: www.kelba.com

KELBA KPS-G-3000-1200 Galvanised Platform Scale

Kelba's KPS-G-3000-1200 x 1200mm NMI (Trade Approved) platform scale provides fast accurate weighing of bulk goods. Built in Australia the KPS-G-3000-1200 is built to a standard with no compromise yet is offered at a competitive price. It's heavy duty extruded C Channel frame is designed to offer the user many years of reliable service. Easy electronic corner adjustment can be done via accessing the stainless steel junction box via access hatch in the top deck.



KPS-G-3000-1200 Platform Scale



Ball & Cup Feet



KPS-G-3000-1200 series stainless junction box access



Underneath C Channel Construction

Features

✚ Australian Made	✚ Adjustable Ball & Cup Feet
✚ Galvanised Finish	✚ Stainless Steel Junction box
✚ NMI approved	✚ Kelba KL1000ZC3 - IP67 load cells
✚ Heavy Duty design	✚ Loadcells protected within the C Channel
✚ Robust Extruded C Channel design	✚ Level bubble equipped

Specifications

Model	Capacity	Gradations	Platform Size	Finish	Shipping Weight
KPS-G-3000-1200	1500kg 3000kg	0.5kg 1kg	1200mm x 1200mm	Galvanised	130kg
Junction box access:	Via side drawer				
Operating Temperature:	-20 °C to + 60°C platform scale only				
Storage Temperature:	0°C to 50°C				
Operating Humidity:	85%R.H				
Display Reading:	Indicator dependant				
Platform Scale NMI Approval:	6/9C/304				
Loadcell NMI Approval:	S155B				
Feet:	Ball & cup feet adjustable				
Junction box:	Stainless Steel				
Warranty:	1 Year excluding loadcells which are 3 years.				