

## KELBA KPS-SS series Stainless Steel Platform Scales

**Kelba's** KPS-SS series of NMI trade approved stainless steel platform scales come in four sizes - 800 x 800mm, 1200 x 1200mm, 1500 x 1500mm and 2000 x 2000mm. Built to a standard not a price yet remain reasonably priced. These scales come with a smooth top deck for easy cleaning and are ideally suit in all food manufacturing, wet areas, harsh chemical environments etc and can be ATEX certified with an optional approved indicator & junction box. At the heart of each scale is the loadcell and for this reason Kelba use the Scaime SK30X trade approved series of IP68 Hermetically sealed shearbeams from France, which carries a 3 warranty, refer to separate data sheet for full specifications.



KPS-SS series Platform scale



Stainless Steel Ball & Cup Feet



Stainless Steel Junction Box



Underneath C Channel Construction 1200 x 1200mm

## Features

✚ NMI Trade approved Scale	✚ Robust C Channel design
✚ Low Profile, with smooth top deck	✚ Stainless Steel Junction box
✚ 304 Grade Stainless Steel	✚ Stainless Steel Adjustable Ball & Cup Feet
✚ Level bubble equipped	✚ Loadcells protected within the C Channel
✚ Choice of Indicator displays	✚ Scaime IP68 Hermetically sealed load cells

## Specifications

Model	Capacity	Gradations	Platform Size	Finish	Shipping Weight
KPS-SS-1500-800	1500 kg	0.5kg	800mm x 800mm	304 Grade stainless	110kg
KPS-SS-3000-1200	1500 / 3000 kg	0.5 / 1kg	1200mm x 1200mm		130kg
KPS-SS-3000-1500	1500 / 3000 kg	0.5 / 1kg	1500mm x 1500mm		150kg
KPS-SS-3000-2000	1500 /3000 kg	0.5 / 1kg	2000mm x 2000mm		170kg
Junction box access:		Via side drawer			
Operating Temperature:		-20 °C to + 60°C platform scale only			
Storage Temperature:		0°C to 50°C			
Operating Humidity:		85%R.H			
Display Reading:		Indicator dependant			
Platform Scale NMI Approval:		6/9C/304			
Loadcell NMI Approval:		S453			
Feet:		Stainless Steel ball & cup			
Junction box:		Stainless Steel			
Warranty:		1 Year excluding loadcells which are 3 years.			